

E-TRACK Compact Power Track User Guide



Product Overview Pre-wired with 3m of 1.5mm² 3-core cable





Place E-TRACK at desired location and Snap support stands onto the rear of E-TRACK. Refer to step 2 for positions of support stands.

connect to the nearest power outlet.



Directions For Use (Free-Standing) - Continued

Align locator to V-Groove as shown and insert adaptor.



Insert plug and turn clockwise to engage

Directions For Use (Free-Standing)



Illustration shows orientation of support stands for free-standing.




Image shows the position of support stands.

3 Years Limited Warranty

- Eubiq Pte Ltd ("Eubiq") warrants to the end-user of the product ("the Customer") that the product will be free from defects in materials and workmanship under normal use for a period of three (3) years from the date of retail purchase by the original end-user purchaser ("Warranty Period")
- The Customer should access and refer to Eubig's website at www.eubig.com for a list of Eubig authorised dealers to contact for
- All requests for warranty service must be made within the Warranty Period, and be accompanied by the original dated proof

Directions For Use (Wall-Mount)






Illustration shows orientation of support stands for wall-mounting.






Snap support stands onto the rear of E-TRACK. Refer to step 2 for positions of support stands.



Measure and mark the locations for drilled holes as shown at the desired wall-mount location of E-TRACK. Use a levelling tool if necessary.




Drill holes on the markings made in step 3. Concrete Drill bit Ø 5.5mm.



Insert wall plugs into the drilled holes, using a mallet if necessary.

Directions For Use (Wall-Mount) - Continued






Fasten screws onto the wall plugs. Leave a gap of 4mm between the screw head and the wall surface for mounting.



Align the opening on the sides of the supports stands to the screw heads. Slot the E-TRACK onto the screw heads.



Apply a downward force to secure the E-TRACK onto the wall.



Align locator to V-Groove as shown and insert adaptor.



Insert plug and turn clockwise to engage power.